Frame-building instructions

Supplies:
Two 1x4x6 pine planks
Two 1x4x8 pine planks
One flat, queen-size bedsheet (black or navy)
Eight 1.5 inch wood screws
Screw gun
Electric stapler
Staples

- 1. Place the 6 foot pieces on top of the 8 foot pieces and square the corners
- 2. Sink two screws into each corner

Important: Some of you who are handy may be tempted to "improve" on these building instructions. Please DON'T! While we appreciate your creativity and the desire to go above and beyond, the frame really does need to be constructed as described. Thank you!

